


PSVITA_{DOCK}

PSVITADOCK DOCUMENTATION

ERRORS

1. PSVita is showing on your screen but you dont have sound or it shows the "No audio" sign on the right side of the screen.



Solution 1: Make sure you have a suffix "PSVita" at your audio input title name where your PSVita is connected.

E.g: Go to Sound Settings then Recording find where your PSVita is Connected for example "Microphone Line-In Front" or "Audio Line-In Rear" double click and rename it by adding the suffix or prefix "PSVita" so it should be like "Audio Line-In Rear PSVita".

Solution 2: If you have sound but the icon is still stuck at the corner go to Sound Settings Recording and pick as default recording device something else except the PSVita.

2. PSVita shows as disconnected even tho i connected it to my computer.



PSVITA is not connected!

Solution 1: There's a big chance you don't have Xerpi's UDCD USB Video Class plugin installed and working on your PSVita.

Download xerpi's plugin https://github.com/xerpi/vita_udcd_uvc.

Solution 2: Connect your PSVita first through usb to your computer and then launch the application PSVitaDock.

3. For some reason i get "PSVita failed to start" with a red PlayStation logo.



PSVITA failed to start!

Solution 1: There's possibly an app already using your PSVita make sure you have all apps closed before opening PSVitaDock.

Solution 2: Disconnect your PSVita from your computer and re-connect it back.

Solution 3: Restart your Computer.

4. The gameplay is jagging.

Solution: Press tab to change from HQ to smooth and vice-versa.

5. The audio has noise.

Solution: Go to your PSVita Settings -> System and disabled power from usb.

SHORTCUTS

ESC (Escape): Goes fullscreen or windowed.

TAB: Changes the quality from HQ to Smooth or vice-versa.

SPACE: Takes a screenshot.